

Description


The **ESWITCH** is an encoder speed/position sensing device with an isolated SPDT relay output. This product uses incremental encoder feedback to serve as a speed switch or as a position switch. The relay will be activated for 1 second when the speed threshold is exceeded or if the position deviates from the present position by a programmable threshold. Two encoder connectors are provided in parallel to make it convenient to loop the encoder signals through the **ESWITCH**. The **ESWITCH** is programmed by a series of 12 DIP switches. DIP switch 12 is not used.



Features

- ▶ Wide 6-25V supply range
- ▶ Covers most useful RPM ranges with 256 CPR encoder
- ▶ Simple DIP switch programming
- ▶ Isolated relay output

Mechanical Drawing



Electrical

Parameter	Min.	Typ.	Max.	Units	Notes
Supply Voltage	6		25	V	
Supply Current		110		mA	12V power, no encoders
Voltage Out to Encoder	4.8	5.0	5.2	V	@100mA load
Encoder Current			250	mA	5V power out for encoder
Quadrature Input Frequency			400	kHz	
Quadrature Encoder Inputs - Logic Low	0	0.4	0.8	V	Diode clamped to ground, 5k pullup to 5V
Quadrature Encoder Inputs -Logic High	2.0	5.0	5.75	V	Diode clamped to ground, 5k pullup to 5V
Relay Contact Rating			2.0	A	External "catch" diode should be used for inductive loads
Relay Dielectric Strength	500			VAC	Open contacts
	500			VAC	Contacts to Coil
Relay Contact Resistance			100	uohms	

▸ The ESWITCH is normally powered through the power connector, but it may also be powered via J1, pin 5.

Speed Sensing Mode

DIP Switch SW11 = "up" for this mode.

In speed sensing mode, the relay will activate for approximately 1 second when the sensed RPM is equal to or greater than the RPM threshold. DIP Switches SW1 to SW10 are used to set the threshold value. The output relay has both normally open and normally closed contacts available to the user.

The CPR of the encoder must be chosen according to the desired RPM range:

Encoder CPR	RPM range
200	28 to 7004
256	21 to 5470
512	11 to 2736
1024	6 to 1268

DIP switch SW10,SW9,SW8 setting:

Calculate the PRESET value from the desired RPM threshold, RPMT and the encoder CPR using the formula:

$$\text{PRESET} = 1920 / (\text{RPMT} * \text{CPR})$$

Look up the SW10/SW9/SW8 setting based on the PRESET value using the table below and note the corresponding PREOUT constant value. If PRESET is outside the range of the table, lower the encoder CPR to get the value within range.

PRESET Range	SW10	SW9	SW8	PREOUT
0.1747601 to 0.3495300	↓	↓	↓	0.3495300
0.0873811 to 0.1747600	↓	↓	↑	0.1747600
0.0436911 to 0.0873810	↓	↑	↓	0.0873810
0.0218451 to 0.0436910	↓	↑	↑	0.0436910
0.0109231 to 0.0218450	↑	↓	↓	0.0218450
0.0054614 to 0.0109230	↑	↓	↑	0.0109230
0.0027308 to 0.0054613	↑	↑	↓	0.0054613
0.0000000 to 0.0027307	↑	↑	↑	0.0027307

DIP Switch SW7 to SW1 setting:

Calculate the offset value as shown below:

$$\text{OFFSETV} = ((\text{RPMT} * \text{CPR} * \text{PREOUT}) / 15) - 128$$

Convert the OFFSETV to binary and enter the value on SW7 to SW1. SW7 is the most significant bit. DIP Switch down = 0 and DIP Switch up = 1

Position Sensing Mode

DIP Switch SW11 = "down" for this mode.

In this mode, an internal up / down counter will decode quadrature states and track the position of the external encoder. DIP switches SW1 through SW7 allow the user to set the number of counts from 1 to 127 in binary. SW7 is the most significant bit. DIP Switch down = 0 and DIP Switch up = 1. The relay will be activated for about 1 second when the counter deviates from the current position by the programmed count value. The counter will auto-reset to zero whenever the trigger point is reached. The output relay has both normally open and normally closed contacts available to the user.

Example:

If the DIP switches are set to 12 in binary, then the relay output will be activated for 1 second when the shaft rotates 12 quadrature states in either direction. The shaft will need to deviate from the current position by 12 quadrature states to activate again.

Pin-outs

Encoder Input/Output

Pin	Description
1	Ground
2	Index
3	A channel
4	+5V power

Pin	Description
5	B channel

J1 Connector

Pin	Description
1	Ground
2	Relay Common Contact
3	Relay N.C. contact
4	Relay N.O. contacy
5	Input Supply Voltage

Included Accessories

PS-12 Power supply

Ordering Information

ESWITCH -

Mounting

D =Default

R =DIN rail (35mm wide)

Notes

- Cables and connectors are not included and must be ordered separately.
- US Digital warrants its products against defects in materials and workmanship for two years. See complete warranty for details.